


Operating/assembly instructions for ergo roller board


Thank you very much for choosing a **SPORT-THIEME** product. We want to make sure that you can enjoy this product, so here is some important advice for your safety as well as for the use and maintenance of the equipment. Please read these instructions fully before you assemble and use the equipment.




The ergo roller board is made from sturdy plywood with a clear varnish. For optimum rolling, the roller board is fitted with particularly easy-rolling, ball-bearing-mounted swivel castors. The high-quality swivel castors have hard-wearing, non-abrasive solid rubber tyres that guarantee a long lifespan. The gripping recesses protect the hands and make safe riding easier. The roller board has additional holes for optional accessories such as the 'towing' rope*.

The ergo roller board is designed for a maximum load of **120 kg** and is only suitable as a piece of indoors sport and leisure equipment.

Make sure your hands do not get into or under the castors. The roller board is only suitable **for its intended use**. Improper use voids the warranty.



Storage trolley (Prod. no.: 131 0102)*



Ergo roller board with 'towing' rope*

The products marked * are not included.

Caution: Do not overload or stand on the roller board!



Maintenance and care instructions

Instructions:

Carry out a visual check at regular intervals. Due to our continuous quality control of the products, technical changes may occur which may lead to slight deviations in the instructions.

Check at regular intervals that the screw connections are tight.

Check the equipment for possible damage and replace worn-out parts. Check the condition of wooden elements as chipping and other signs of wear can result from use. Ensure that moveable parts are free-moving.

We are happy to answer any questions
you may have.

Your **Sport-Thieme** Team